

IMPORTANT PLEASE TAKE NOTE

MAXI VAC REAR DOOR – CLOSING NOTES Please note as all plastic is different our larger Maxi Vac doors require adjustment by hand before clamping the rear door closed. It is essential that the rear door is seating properly in the channel of the main body -



(1)



(2)

The photo (1) above shows the door NOT seating properly – attempting to clamp in this position will cause damage to your clamp.

The above photo (2) shows the door in it's correct position, before clamping.



This photo shows how to seat the door before clamping – simply push in on the side wall while pulling the bottom of the rear door upward.

***** CLAMPING THE DOOR BEFORE CORRECTLY SEATING WILL CAUSE DAMAGE**